

REPLACEMENT PARTS ILLUSTRATION

Customer Service
1-817-293-3331

IMPORTANT RESTRICTION


THE INFORMATION CONTAINED HEREIN IS FOR EXCLUSIVE USE OF THE MANUFACTURERS CUSTOMERS. NEITHER THE SHEETS NOR THE INFORMATION CONTAINED THEREIN ARE TO BE COPIED OR REPRODUCED WITHOUT THE PRIOR WRITTEN CONSENT OF THE MANUFACTURER. ALL RIGHTS WHICH THE MANUFACTURER HAS OR OBTAINED THEREIN, INCLUDING PATENT RIGHTS ARE EXPRESSLY RESERVED BY THE MANUFACTURER.

IMPORTANT NOTICE


IF AN INSTALLATION IS MADE ON ANOTHER VEHICLE OTHER THAN SPECIFIED, THE FACTORY WILL NOT INCUR ANY EXPENSE FOR LABOR, TIME AND MACHINE EXPENSE TO MAKE THAT PARTICULAR INSTALLATION. ANY DEVIATION FROM PRODUCT DESIGN COMPONENT OR THE USE OF OTHER MATERIAL, PARTS AND/OR SYSTEM COMPONENTS WILL BE WITH THE INSTALLER'S RESPONSIBILITY FOR ANY SUCH CHANGE OR DEVIATION.

(A) Power Unit 089-00014


1 - BACK VIEW




2 - FRONT VIEW




3 - END VIEW - COMPRESSOR




4 - END VIEW - GENERATOR



5 - TOP VIEW



6 - APU - BACK




7 - APU - FRONT

Oil Tank Crankcase
Gas Separator
054-00154

Air Filter Service
Element Kit 1 of Filter
093-00804

Individual Filters
Gray Foam
045-00667
White Foam
045-00668
Paper Filter
045-00666
(Not Shown)

Crankshaft
Seal (Not Shown)
045-00626
Crankshaft Seal
Protector
024-00089



Engine Oil Pressure Switch
032-00380


Hood Latch
022-00080

Grommet
021-00104

8 - APU

Straight Linkage
073-00078

Metal Ball Joint
073-00085



Water Pump
080-00034


Water Hose 3/4 x 90
051-00414

9 - COVER

Cover Assembly
Power Unit Lid
087-00377




(B) - TRUCK SLEEPER HEAT/COOL KIT 090-00479



2 - EVAPORATOR SIDE VIEW

Evaporator Coil
041-00182

Hose Adapter Cap
060-00686



Heater Coil
042-00067

Expansion Valve
034-00046

Skirt Grommet
021-00033

3 - CONTROL PANEL

Gray
Control Assembly
(Complete Assembly)
083-00336

Gray
Control Panel
(Only No Switches)
060-00773

Red&Green LED
w/Harness
036-00780

Switch - Start / Stop
032-00353

Meter Hour
032-00354

Guard - Temperature Probe
062-00711

Knob (2)
062-00640 (ea.)

Nut Hex
(Not Shown)
023-00018

Switch - Mode Control
032-00362



Bracket - P.C. Board
071-00968

Switch Temperature Control
032-00370


P.C. Board
035-00078

Relay (2)
031-00001

Screw - PTH #8 x 3/8
025-00042

Switch Rotary-Fan
032-00063

P.C. Board
035-00065




Wire Harness
Start/Stop
036-00763

Wire Harness
AC / Heat Control
036-00717

*Sold Separately from
Control Assembly*


(C) - INSTALLATION KIT

PN: 093-00679



(D) - DUCT KIT

093-00660



(E) - HOSE KIT

PN: 093-00658

#12 Hose Assembly
(10 ft.)
085-00609

#6 Hose Assembly
(10 ft.)
085-00568

5/8 ID (35 ft.)
Heater Hose
051-00005



Radiator Cap
024-00076

Water Valve
034-00138

Surge Tank
(After 03/08)
054-00156

Surge Tank
(Before 03/08)
087-00342

Wire Harness
Extension
036-00682

Sack Assembly
082-00502

3/4 ID (15 ft.)
Heater Hose
051-00019

Fuel Filter Assembly
(After 03/08)
093-00802
Fuel Filter Only - 045-00662



Fuel Filter Head /Bracket
Only
070-01105